

## GRAND PORT FLUVIO-MARITIME DE L'AXE SEINE – Direction Territoriale de Rouen

Capitainerie Rouen - 34 Bld de Boisguilbert - BP 4075 - 76022 Rouen cedex 3 Tél 24/24 h : +(33) 02 35 52 54 00 - Fax (33) 02 35 52 54 02

harbourmaster@haropaport.com - www.haropaport.com

# NOTICE TO MASTERS / NOTE AUX CAPITAINES FLOOD TIDE / RENVERSE DE BASSE MER

Snip's name :	Bertn :	( 1+	)
Nom du navire :	Poste du navire :		

Masters are advised that the flood tide (at time of local low tide) makes a ship to move along her berth and can break ropes. Therefore it is necessary:

- THAT ALL ROPES BE STRONGLY TIGHT HALF AN HOUR BEFORE THE LOCAL LOW TIDE TIME.
- THAT GANGWAY BE HEAVED UP, PIPES AND MANIFOLDS DISCONNECTED AND BOOMS, DERRICKS, GANGWAY LIGHTS (whatever equipment outside plating) BE PULLED INSIDE.

Les Capitaines sont informés qu'à la renverse de basse mer (qui correspond à l'heure de la basse mer locale), le phénomène entraîne le déplacement du navire le long de son poste et peut occasionner des ruptures d'amarres.

\*\*\*\*\*\*

### Il convient donc:

- QUE LES AMARRES SOIENT BIEN RAIDES 1/2 HEURE AVANT L'HEURE PREVUE DE LA RENVERSE ;
- DE DEBRANCHER LES COLLECTEURS, REMONTER LA COUPEE ET RENTRER MATS DE CHARGE, PROJECTEURS DE COUPEES ....., (tout ce qui déborde la muraille),
- ➤ Pour les prochains jours, les horaires des renverses prévues à LA BOUILLE, aux heures **T** ci-dessous (avance ou retard possible jusqu'à 20 minutes) :
- > For next days bore is expected at LA BOUILLE at following hours (possible 20 mn earlier or later).

On Le	Saturday Samedi	14	October Octobre	2023	at à	11h06	and et	23h21	coefficient	84 / 86
On Le	Sunday Dimanche	15	October Octobre	2023	at à	11h37	and et	23h52	coefficient	88 / 89
On Le	Monday Lundi	16	October Octobre	2023	at à	&	and et	12h07	coefficient	& / 89
On Le	Tuesday Mardi	17	October Octobre	2023	at à	00h22	and et	12h37	coefficient	88 / 87
On Le	Wednesday Mercredi	18	October Octobre	2023	at à	00h55	and et	&	coefficient	85 / &
On Le					at à		and et		coefficient	/
On Le					at à		and et		coefficient	/
On Le					at à		and et		coefficient	/

Rouen, le / / Harbourmaster Officer Reçu du Commandant du navire (1) Accept of Captain of Master, (1) NOM/NAME

Signature/Visa

#### NOTICE TO MASTERS / BORE

In the river Seine, the tidal bore, which is a body of water rushing up the river, occurs at spring tides and at several tides preceding and following spring tides.

For the river Seine, it means that bore occurs when the height of the high tide in Le Havre is more than 7.60 meters or when the French tide coefficient is higher than 85 (see tide tables). The greater this height or this coefficient is, the stronger the bore is.

This phenomenon is characterised by a kind of wave, more or less visible, sometimes even difficult to see, which goes up the river and whose power varies according to the height of the tide and the flow of the river. The strength of the bore is very difficult to foresee.

The bore's arrival, corresponding with the local low tide time, can make vessels move and can even lead to the breaking of moorings when it is strong enough, or when ropes are not securely fastened.

During a period with bore, a forecast sheet, called "notice to masters", is given by port officers to all present vessels likely to be affected by the phenomenon. If you don't have it on board, ask for it from your agent.

#### Therefore, it is essential:

- that all ropes are securely fastened half an hour before the expected time of the bore's arrival at the berth.
- that the gangway is raised up, pipes and manifolds are disconnected, booms, derricks, gangway lights and so on, are pulled inside.
- that engines are ready half an hour before the bore's arrival.
- to monitor VHF channel 73 (listening to "Rouen Port" station) half an hour before scheduled time at "La Bouille". The bore is announced on VHF channel 73 when passing "La Bouille".

#### Please, note also that:

- the bore can be up to 20 minutes earlier or later than the scheduled times at "La Bouille"
- all vessels must be careful of the bore, but vessels berthed heading upstream and/or vessels with a deep draught (regardless of the heading) are usually more sensitive to the bore.
- all schedules are given in local time at "La Bouille" and must be increased by the time indicated for your berth.
- for safety reasons, and pursuant to French Law, the use of a pilot and/or tug(s) and/or boatmen and/or shore lines may be imposed by the Harbour Master's office, at the expense of the vessel.
- If desired, pilot and/or tug and/or boatmen assistance can also be directly requested by the Captain (pilot is mandatory when a tug is to be used).

Visa Captain of master

